

EZOdor™ Odor Eliminator

Review all instructions prior to using the product.



Prepare the Vehicle:

Before performing a treatment, ensure the vehicle has been properly detailed. Ensure all seat belts are buckled, sun visors are lowered, and all compartments are open. Ensure all windows are rolled up and the sunroof is closed. Start the vehicle and set the heat or A/C between 72–77°F depending on the time of year. Set A/C to recirculating with the blower on high and airflow directed to vents (including rear vents if applicable), confirm that all air vents are open.

Perform a Treatment:

To begin the EZOdor treatment, fill the treatment cup to the appropriate line with room-temperature water. Install the EZOdor treatment warning flag and clock on the driver's door. Place the treatment cup in the front cup holder (or center console on larger vehicles). Open tablet packets labeled A and B, prepare to exit the vehicle, empty both packets into the treatment cup simultaneously and exit the vehicle. Close the door immediately and set the clock for 5 minutes.

Complete the Process:

After 5 minutes have elapsed, open all doors and the trunk (if applicable) without entering the vehicle. With all doors open, keep the A/C blower on high, but turn off recirculating air. Roll down all windows and allow the vehicle to air out for at least 5 minutes. Remove and dispose of the treatment cup contents, rinse the cup if needed and remove the EZOdor treatment flag and clock.

EZ
Fleet Solutions

🌐 ezfleetsolutions.com
📞 (855) 439-6367



01 CHECK LIST:

- Vehicle cleaned and detailed
- All seatbelts buckled
- Sun visors down
- Compartments open
- Vehicle started
- Windows up/sunroof closed
- Heat/A/C set between 72–77°F
- A/C on recirculate
- Blower on high and set on vents
- Rear air (if applicable) set the same

02 CHECK LIST:

- Fill EZOdor cup to fill line with room-temperature water
- Attach warning flag and clock to driver door
- Place cup in front or center cupholder (larger vehicles)
- Open packets A and B
- Prepare to exit vehicle
- Pour both packets into cup at the same time
- Exit vehicle and close door immediately
- Set clock timer for 5 minutes

03 CHECK LIST:

- After 5 minutes, open all doors and trunk
- Blower on high
- Turn off recirculate
- Roll down all windows
- Air out vehicle for at least 5 minutes (More time and fresh air = better results)
- Remove EZOdor cup
- Empty and rinse cup if needed
- Remove flag and clock